

*13th International Conference on Fracture  
June 16–21, 2013, Beijing, China*

**Development and Several Additional Performances of  
Dual-Spindle Rotating Bending Fatigue Testing Machine  
*GIGA QUAD***

1 YAMAMOTO METAL TECHNOS CO. LTD.,  
4-7 SETOGUCHI 2-CHOME, HIRANO-KU, OSAKA, 547-0034 JAPAN

2 RITSUMEIKAN UNIVERSITY,  
1-1-1 NOJIHIGASHI, KUSATSU, SHIGA, 525-8577 JAPAN

3 TOYOTA NATIONAL COLLEGE OF TECHNOLOGY,  
2-1 EISEICHO, TOYOTA, AICHI, 471-8525 JAPAN

*13th International Conference on Fracture  
June 16–21, 2013, Beijing, China*

# **Development and Several Additional Performances of Dual-Spindle Rotating Bending Fatigue Testing Machine *GIGA QUAD***

- 1) Background
- 2) Development of New Testing Machine
- 3) GIGA QUAD Outline
- 4) **Main environmental options**
- 5) Concluding Remarks



# Background

## Background 1

Recently, particular attention has been paying to the fatigue property of metallic materials **in the very high cycle regime** to realize the low-carbon sustainable society.

But, one of difficulties in fatigue tests **in the very high cycle regime** is to take a long time to perform the fatigue test. If the fatigue test is performed at the loading frequency of 50Hz, it takes 200 days to  $10^9$  cycles.


## Background 2

The fatigue property data in various environments still remain unsolved.

# Development of New Testing Machine

- ★ In order to overcome this difficulty, we have developed special type of fatigue testing machines in rotating bending, in which four specimens can be tested simultaneously. Thus a series of fatigue tests even in gigacycle regime can be carried out within a reasonable period.
- ★ Based on this advantageous performance, the name of “**GIGA QUAD**” was accepted for this new machine. Accordingly, this machine is very useful to file up a number of fatigue test data.





# Dual-Spindle Rotating Bending Fatigue Testing Machine

## <GIGA QUAD Outline>


### GIGA QUAD : YRB200

SIZE OF MACHINE(mm): 470X400X1050  
WEIGHT(Kg): 140




### GIGA QUAD : YRB200L

SIZE OF MACHINE (mm): 800X660X1100  
WEIGHT(Kg): 170





3,150rpm  
(52.5Hz)






# Dual-Spindle Rotating Bending Fatigue Testing Machine < GIGA QUAD Outline >






# GIGA QUAD

## <Main environmental options>



- ① High temperature environmental testing unit
- ② Low temperature environmental testing unit



③ Corrosive environmental unit





④ 2-step variable loading unit

# GIGA QUAD

## <Main environmental options>

### High temperature environmental testing unit




【Temperature controlling range】  
room temperature to 600deg.C  
【Size of control panel box】  
170mm x 220mm x 280mm



# GIGA QUAD


## <Main environmental options>

### High temperature environmental testing unit




Safety mechanism

# Low temperature environmental testing unit




**【Temperature controlling range】**  
-100deg.C. to room temperature  
**【Size of control panel box】**  
170mm x 220mm x 280mm



# GIGA QUAD

## <Main environmental options>

### Corrosive environmental unit








# GIGA QUAD

## <Main environmental options>

### Corrosive environmental unit






# GIGA QUAD

## <Main environmental options>

### 2-step variable loading unit



Maximum load	Range of variable load		
	Diameter of the critical section	Upper side load (MPa)	Lower side load (MPa)
80kg x 4 points	φ 6 mm	173~2491	111~2274
	φ 8 mm	73~1050	47~959



# Concluding Remarks

---

The high performance fatigue testing machine in rotating bending “GIGA QUAD” has been developed in this work.

Based on a lot of experimental results, the fundamental performance of this testing machine was confirmed.

Actually, GIGA QUAD are already being used at many laboratories in universities and industries in JAPAN and several countries.

Thus, every customer has informed that GIGA QUAD is successfully used to obtain a number of fatigue data under many environments within a reasonable short period.

Taizoh Yamamoto  
[yamakin@mx1.alpha-web.ne.jp](mailto:yamakin@mx1.alpha-web.ne.jp)

 **YAMAMOTO**

**Thank you  
for your attention.**